

## Installation note

DEHOUST PE storage tanks are subject to natural physical stresses when filled, which lead to expansion and settlement movements. For this reason, it is necessary to design the on-site container connections stress-free. We recommend flexible components for movement compensation, such as free pipe routing without rigid fastening points, the use of compensators or flexible pipe materials.

The expansion and settlement movements depend on the size of the container, the container contents and the filling level. For this reason, a minimum distance of 100 mm from the nearest wall must be maintained when installing the containers. In the case of a row installation, a minimum distance of 100mm between the single-tent tanks must also be maintained (see example sketch).

In the case of a battery installation with a lower connection line, the DEHOUST installation instructions supplied must also be observed.

